




- Acidic disinfectant
- 5% available Peracetic Acid
- Low foaming and quick rinsing
- PCS No. 98583

USE INSTRUCTIONS	
<b>Disinfection of Milking Plant</b>	Cluster San may be circulated at a dilution rate of 200 - 400ml per 100 litres of clean water (0.2 - 0.4%) for the disinfection of the Milking Plant, following on from an effective clean using a suitable detergent. Ensure the plant is completely drained before milking.
<b>Cluster Dipping</b>	Cluster San may be used for cluster dipping at 500ml per 100 litres of clean water (0.5%).

CLUSTER SAN TECHNICAL DATA	
<b>Cluster San</b> 	Mixing with Blue label products will cause violent chemical reactions Mixing with Yellow label products will produce toxic chlorine gas
<b>pH and SG</b>	< 1 Neat                      1.10 at 20°C
<b>Appearance</b>	Clear, colourless liquid
<b>Shelf Life</b>	1 year from the date of manufacture

Use solutions of Cluster San are safe for use on 304 and 316 Stainless Steel. Cluster San is corrosive to Aluminium, Copper, Zinc and their alloys. Store incompatible chemicals separately in the original containers away from animals and children.

#### PACKS

The product is available in the following pack sizes:

25Kg	200Kg	1000Kg
HDD11/25	HDD11/200	HDD11/1000

